

Best Practices for Garbing in HD Sterile Compounding

DOFFING

1. Remove the Outer Pair of Sterile Gloves in the C-PEC



2. Remove Outer Pair of Shoe Covers



3. Remove Chemo Gown: Begin pulling at the hips to dislodge the fastener in the back. Slowly remove inside out.



4. Remove Inner Gloves: Grasp the outside of the first glove pulling it off inside out. Slide finger underneath the remaining glove, removing it inside out.



5. Leave HD Buffer Room, Remove Non-HD Gown, and Perform Hand Hygiene

