

# WEEKLY EYE WASH INSPECTION

(OSHA STANDARD 1910.151(C))

- Unit is secure, complete, and located in a visible area.
- Access to the unit is unobstructed.  
(No boxes, equipment, etc. can be on the floor in front of the unit. Nothing is stored in the bowl of the unit.)
- Protective eye wash covers are present, placed over the water outlets, and are clean.
- Activate the eye wash station by pushing the designated paddle.
  - Water should flow freely and evenly from both outlets.
  - The outlet covers or flaps should be pushed off or open completely.
  - Water streams should cross each other above the plane of the eye wash station bowl.
  - Let water run for several seconds to flush the sediment out of the outlets.
- Flows must continue until the paddle is pulled back.
- Temperature of the water should be "tepid." (Between 60-100 degrees) If it feels comfortable to the touch, it is fine.
- Reinstall covers or push flaps on the covers back shut.
- Record the test date on the card or sheet provided at the eye wash station.
- Report any deficiencies via Work Order Request on GenNet.